



MagicFire B Receiver PC32Q

Local LCD User's Guide

A. LCD Interface



B. Buttons and the Correlative Operations

 Depress for 3 seconds, go to following step if Substep doesn't exist; like the right.





Press, go to following substep if the substep exists; like the right.








Press to select or disable cue, like the right. Only available when to programme cues.



 Press to shift cursor in widthwise in the right status.



  Press to change value in status like , or move cursor up or down in status like .

 Press to save and return the former step, depress for 3 seconds to save and return to main page.

C. Some Special

- Turn on power, LCD will show the following page and then turn to other page after 3 seconds.



- Directions of 3-position Switch and their LCD indications,




Test


Program

Fire

Only when the switch is at Program, five buttons above are available to LCD.

- At Program mode, when LCD indicates following, press  for 3 seconds, other page will appear.



- Learning Code of Trasmmitter or Clearing Code can be done through depressing  for more than 3 seconds, or through LCD interface:



D. Basic Functions at Program Mode




- Programme: Can locally programme 32 cues one by one or in bulk, or have 32 cues disable.






When programme cues in bulk, you can assign Starting Time and Interval Time, and select either partial free cues or all free cues.



- DEMO: Through LEDs' illumination to display program. You can have DEMO through RFRemotech special transmitter TCF1000-6TX or through local buttons.



- Program List: You can look through the program through pressing  or .
- Learn Code of Transmitter.



- Clear Code of Transmitter. All stored codes are cleared.